



DSIII Pushbutton Configuration Menu (HART)

Mode

1. Default Display Setting
2. Zero Calibration – apply zero pressure and adjust for 4 mA
3. Span Calibration – apply span pressure and adjust for 20 mA
4. Damping – Adjustable from 0-100 seconds
5. Zero Setting/LRV
6. Span Setting/URV
7. Zero for Mounting Effect/Adjust Elevation and Suppression
8. Loop Check Function
9. Failure Mode Selection (upscale or downscale)
10. Pushbutton Lockout
11. Square Root function for flow applications
12. Low Flow cutoff for square root function
13. LCD Display Setting Options – mA, %, or engineering unit
14. Engineering Unit Selection

Technical Support

1-800-333-7421

Documentation

<http://www.usa.siemens.com/pressure>